

Instructions for Use

Please read this leaflet carefully




Warn

1. Don't leave unattended children. Please keep them in sight of adults to ensure their safety;
2. Children should wear seat belts whenever and wherever to ensure their safety;
3. Keep the seat stable before using it, and the dining chair is limited to flat ground.







IMPORTANT: Please read the instructions before installing and using the seat for future reference and keep them as important information

Dining chair component diagram




Component display


Different packages have different components

Seat X1 	T-shaped safety bar X1 	Table Foot X4 Serving feet Lower table legs 	
Hooked Support Bar X1 	Foot Pedal X2 	Short screw X10 	Long screw X2 
Dust Cover X16 	Dinner Plate X1 (Optional) 	Wheels X4 (optional) 	

Screw distribution diagram




Short screw X10 Long screw X2 Hex wrench X1




Installation steps


1 Install foot pedals





2.1 mounting seat



1. Tighten the 6 short screws of 1
2. Align screw holes
3. Install T-shaped safety bar




4.1 mounting backrest



5.1 Install the dust cover and press it in




Dust Cover X16



6.1 mounting tray

Pull open the handles on both sides of the tray with both hands, align them with the chair clamps and press them in



Press the track on the two sides of the quasi-seat on the reverse side of the dinner plate with both hands, and then loosen your hands to buckle the dinner plate!