

ASSEMBLY INSTRUCTIONS

ITEM CODE : IN 3425

ITEM DESCRIPTION :
OPEN SLOT CONSOLE



1

Reverse the console & place
the leg as shown & align the
leg to match the apron.



2

Insert the Bolt to fix
the leg with the console
top and tighten the nut
with the washer as
shown in fig1



3

Fix the other leg in the similar way




Fig. 1

Reverse the desk
straight. Now your
console is ready
for use

4

