
## ASSEMBLY INSTRUCTIONS


**<<Before assembling,check all the hardwares and panels>>**



Hardware:


| Letter | Piece | Number | Letter | Piece | Number |
|---|---|---|---|---|---|
| A | 6x30mm | 38pcs | J | | 2pcs |
| B | 6x35mm | 34pcs | K | | 2pcs |
| C | 15x9.5mm | 34pcs | L | | 2pcs |
| D | | 1pc | M | | 1pc |
| E | 3x12mm | 14pcs | N | 4x12mm | 2pcs |
| F | 4x35mm | 8pcs | O | 4x30mm | 4pcs |
| G | 4x16mm | 1pc | P | | 2sets |
| H | 3x14mm | 8sets | | | |
| I | | 1pc | | | |









①





(B)x12pcs
(M)x1pc
(N)x2pcs

②





Cam Lock Fastening System




(A)x4pcs
(C)x4pcs




③





(A)x4pcs
(C)x4pcs

④




(A)x4pcs
(C)x4pcs


⑤




(A)x4pcs

(B)x4pcs


⑥




(F)x4pcs



⑦





(A)x2pcs

(B)x2pcs

(C)x2pcs


⑧




(O)x4pcs




⑨




(E)x4pcs

(K)x2pcs

⑩





(E)x4pcs

(J)x2pcs




⑪




(D)x1pc

(G)x1pc

⑫





(B)x12pcs

(E)x2pcs


(I)x1pc

13




(C)x4pcs

15





(A)x4pcs

(B)x4pcs

(C)x4pcs

14





(A)x4pcs

(F)x4pcs



16





(A)x8pcs

(C)x8pcs




17




(E)x4pcs


18




(A)x4pcs




19




(C)x4pcs


20




(L)x2pcs


13

21




14


22




(H)x8sets

15

23




(P)x2sets

16