



ASSEMBLY INSTRUCTIONS



Parts List

I	K	L	M	N
				
5 pcs	1 pc	5 pcs	1 pc	1 pc
O	P	Q	R	S
				
Right x1	Left x1	1 pc	1 pc	1 pc
T	U			
				
1 pc	1 pc			

Hardware List

A	B	C	D	E
				
M6*16mm 10 pcs	M6*30mm 4 pcs	M8*35mm 4 pcs	M8*25mm 3 pcs	4 pcs
F	D			
				
1 pc				
3 pcs				

STEP 1



K*1



A*10




I*5



L*5



F*1




Press to install

First, we need to prepare the connector (K), 5*metal feet (I), 5*universal casters (L), 5*15mm screws (Screw A) and a wrench (F). Then, according to the figure, insert the 5*metal feet into the connector, align the screw holes, install the screws and tighten them. Finally, a universal caster is installed on the tail of each metal foot.

STEP 2




M*1



STEP 3




S*1




STEP 4

	T*1
	N*1
	B*4
	F*1




STEP 5

	U*1
	D*3
	F*1





This step requires two people to install. One person stabilizes the backrest of the office chair so that the backrest is aligned with the screw holes in the part "N" while the other person installs the screws.

STEP 6




STEP 7





As shown in the picture, the 2 armrests (O and P) are separately marked with label "P" (Left) and label "O" (Right). Please check and choose the correct one.

STEP 8



After fastening the screws, use part (E) to cover the screw holes.

STEP 9



Function Explanation of Remote Control Buttons

⏻ : Power Button: On/Off

▲ : Press the triangular button to switch and select from eight massage modes.

🔊 : Press this button to turn on/off the heating function.

⏩ : Press the plus (+) button to increase the massage intensity.

⏪ : Press the minus (-) button to decrease the massage intensity.

🔊 : Press this button to switch and select the massage area.

Operating Steps of Remote Control

Step1: Plug in the power plug, press the button ⏻ to turn on the remote control.

Step2: Press the button 🔊 to select the massage area, there are three different massage areas, which you can customize according to your preference.

Step3: Press the button 🔊 to turn on/off the heating function. Adhering to the concept of safety first, the heating temperature of this office chair is up to 140 degrees Fahrenheit, it is recommended that you take off the thick coat when using indoors in winter.

Step4: Press the triangle button ▲ to select the massage mode. The numbers 1 to 8 represent eight different massage modes, which you can customize according to your preference.

Step5: Once you've set the massage mode, then press the plus button ⏩ or minus button ⏪ to adjust the massage intensity. There are 3 massage intensities.

When indicator light 1 is on, it indicates the weakest massage intensity, and when indicator lights 1 to 3 are all on, it indicates the strongest massage intensity.

