
## ASSEMBLY INSTRUCTIONS


**<<Before assembling,check all the hardwares and panels>>**



Hardware:


| Letter | Piece | Number | Letter | Piece | Number |
|---|---|---|---|---|---|
| A | 6x30mm | 63pcs | J | | 2pcs |
| B | 6x35mm | 42pcs | K | 4x14mm | 12pcs |
| C | 15x9.5mm | 42pcs | L | | 2pcs |
| D | | 1pc | M | | 1pc |
| E | 3x12mm | 3pcs | N | 3x14mm | 2pcs |
| F | 4x35mm | 8pcs | O | | 1pc |
| G | 4x16mm | 1pc | P | | 2pcs |
| H | 3x14mm | 16sets | Q | | 2sets |
| I | | 1pc | | | |









①




(B)x6pcs
(E)x2pcs
(I)x1pc


②





(A)x5pcs
(F)x2pcs



③





Cam Lock Fastening System





(A)x2pcs
(C)x2pcs

④





(A)x4pcs
(C)x2pcs

⑤




(B)x20pcs

⑥





(A)x8pcs

(C)x5pcs




⑦




(A)x4pcs


(C)x2pcs

⑧







⑨




(A)x8pcs


(C)x5pcs

⑩







⑪




(A)x4pcs

(F)x6pcs

⑫





(B)x16pcs

(M)x1pc


(N)x2pcs

13





(A)x7pcs
(C)x4pcs

15




(A)x2pcs
(C)x4pcs


14




(A)x7pcs
(C)x4pcs

9


16




(A)x2pcs
(C)x2pcs


10

17




(C)x2pcs
(E)x1pc
(O)x1pc


18




(L)x1pc
(P)x1pc

11


19





(A)x10pcs
(C)x10pcs
(L)x1pc
(P)x1pc

12

20





| | |
|---|---|
| | (D)x1pc |
| | (G)x1pc |
| | (J)x2pcs |
| | (K)x12pcs |

13


21




(H)x16sets

14


22





(Q)x2sets

15

23





16