



PRIAM U



- | | |
|-------------------------------|-----------------------------|
| Ⓓ Montageanleitung | ⒽⒺ Szerelési útmutató |
| Ⓔ Handleiding voor de montage | ⒽⒻ Instrukcja montażu |
| ⒽⒼ Montage tallmatl | ⒽⒼ Инструкція по монтажу |
| Ⓕ Notice de montage | ⒽⒼ Istruzioni di montaggio |
| Ⓕ Montážní návod | ⒽⒼ Návod na montáž |
| ⒽⒼ Assembly Instructions | ⒽⒼ Instrucțiunile de montaj |



W1/3



W2/3



W3/3



A



x9

B



x18

C



x5

D







x5


E



x18



II



III

