

Instruction Manual

B36

PARTS LIST

A BACK 1PC	B SEAT 1PC	C ARMREST 2PCS L R	D MECHANISM 1PC	E GASLIFT 1PC	F LEG 1PC
G WHEELS 5PCS	H HEADREST 1PC	I Headrest Plug 2PCS	J SCREW 1 2 3 4 M6X20MM 4PCS M6X30MM 6PCS+1PC M6X35MM 2PCS+1PC M8X40MM 3PCS+1PC	K LEG COVER 1PC	L Allen key TOOL SMALLX1 BIGX1

INSTALLATION STEPS

