











TOM 377570i EN











1		X 2	7		X 1
2		X 1	8		X 1
3		X 1	9		X 1
4		X 1	10		X 2
5		X 1	11		X 2
6		X 2	12		X 1



13		X 2	26		X 1
14		X 1	27		X 1
15		X 1	28		X 1
16		X 1	29		X 1
17		X 1	30		X 1
18		X 1	31		X 1
19		X 1	32		X 1
20		X 1	33		X 4
21		X 1	34		X 1
22		X 4	35		X 1
23		X 2	36		X 2
24		X 2	37		X 1
25		X 4			



	Ø6x30	12
	Ø6x12	11
	Ø6x15	8
	Ø6x12	40
	Ø6x16	4
	Ø4x12	1
	Ø8	1
	Ø6	24
	Ø4	1
 Fiber	Ø6	10
 Fiber	Ø4	1
	Ø8	2
	Ø6	24
 Brake nut	Ø4	1
	Ø8	1
	Ø8	1
	5	1































Cuisson directe



Cuisson indirecte

