


ASSEMBLY INSTRUCTIONS

ITEM CODE : IN1763

ITEM DESCRIPTION : NORDIC WRITING DESK WITH 1 DRAWER

1

Reverse the writing desk
& place the leg as shown & align
the leg to match the apron.



Insert the Bolt to fix
the leg with the writing desk
top and tighten the bolts
with the washer as
shown in fig 1.

2



3

Fix the other pair of legs in the similar way



4

Reverse the writing desk
straight. Now your
writing desk is ready for use.



fig 1.

