





CHAIR ASSEMBLY MANUAL



PARTS OF THE CHAIR




① Base(1&2)




② Head&Lumbar Pillow




③ Armrest (L& R)




④ Tilt Mechanism




⑤ Caster




⑥ Cylinder & Cover




⑦ Backrest Support




⑧ Backrest



⑨ Screws, joints and adjustment tool




⑩ Cushion



X1


① M6*30MM




X4

Tilt Mechanism Screws(Pre-installed)


HOW TO ASSEMBLE THE CHAIR




Insert the Base-2 to Base-1 as shown.




Insert the wheels directly in the hole of nylon base




Insert the gas lift and gas lift cover into the base as shown.




Remove the pre-installed screws Install the mechanism




Insert gas lift to the hole of the mechanism



Assemble the steel plate on the backrest by 4 screws then insert it in the seat then assemble the rest 3 screws



Fix the headrest and lumbar pillow as shown.



Fix the armrest in the seat and backrest as shown