



Aufbauanleitung / Assembly instructions / Instructions de montage / Istruzioni di montaggio / Instrucciones de montaje

DINING CHAIR MODEL#: TC-2469A







Item No.: 112983 112984
 112985 112986
 112987 112988

PARTS CHECKLIST

<p>① Seat</p>  <p>X 1</p>	<p>② Chair leg</p>  <p>X 4</p>	<p>③ Connect Plate</p>  <p>X 1</p>
<p>④ Swivel Parts</p>  <p>180° X 1</p>		


HARDWARE IDENTIFICATION

<p>A Bolt</p>  <p>M6x16 X 8</p>	<p>B Bolt</p>  <p>M6x10 X 4</p>	<p>C Bolt</p>  <p>M6x18 X 4</p>
<p>D Washer</p>  <p>Ø6x16 X 16</p>	<p>E Allen Key</p>  <p>5# X 2</p>	




1

Note:
Screw tightening 100%




2

Note:
Screw tightening 80%




3

Note:
Screw tightening 100%



4



Note:
Screw tightening 100%

