

ASSEMBLY INSTRUCTIONS

ITEM CODE : IN168

ITEM DESCRIPTION : NORDIC WRITING DESK WITH 2 DRAWERS

1

Reverse the writing desk
& place the leg as shown & align
the leg to match the apron.



2

Insert the Bolt to fix
the leg with the writing desk
top and tighten the bolts
with the washer as
shown in fig 1.



3



Fix the other pair of legs in the similar way



4

Reverse the writing desk
straight. Now your
writing desk is ready for use.




fig 1.

