

ASSEMBLY INSTRUCTIONS

ITEM CODE : IN1491

ITEM DESCRIPTION : 4 DRAWER MEDIA UNIT

1

Reverse the unit top & place the leg as shown & align the leg to match the apron.



2

Insert the Bolt to fix the leg with the console top and tighten the nut with the washer as shown in fig1



3

Fix the other pair of leg in the similar way





Fig. 1



Reverse the media unit straight. Now your media unit is ready for use

4

