

ASSEMBLY INSTRUCTIONS

ITEM CODE : IN 3326

ITEM DESCRIPTION : 1 DRAWER CONSOLE TABLE

1

Reverse the console top & place the leg as shown & align the leg to match the apron.



Insert the Bolt to fix the leg with the console top and tighten the nut with the washer as shown in fig1

2



3

Fix the other pair of leg in the similar way





Fig. 1



Reverse the console straight. Now your console is ready for use

4

