




D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



1/4

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

TOLEDO 2DL.OTM(OTM.2DL)

M8X50



B1-6




B2-6

M6X20



B3-12



B4-4




B5-2

M6X50





B6-4




13




30 min




h-170




h-170




E3-10




E4-10




C1-3



2DL.OTM




OTM.2DL





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



2/4

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

TOLEDO 2DL.OTM(OTM.2DL)

M8X50



B1-6




B2-6



B3-12



B4-4




B5-2

M6X50




B6-4




h-170

E1-7




h-170

E2-3



E3-10




E4-10



C1-3

OTM.2DL

2DL.OTM





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



3/4

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

TOLEDO 2DL.OTM(OTM.2DL)

M8X50



B1-6



B2-6

M6X20



B3-12



B4-4



B5-2

M6X50



B6-4



h-170




E1-7

h-170



E2-3











E3-10



E4-10






C1-3






2DL.OTM

OTM.2DL




2DL.OTM

OTM.2DL





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
 PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
 RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
 SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



4/4

Name-Naam-Nazwa-Isim-Название-Nom-Nome-Názov-Név

TOLEDO 2DL.OTM(OTM.2DL)

M8X50



B1-6



B2-6

M6X20



B3-12



B4-4




B5-2


M6X50



B6-4



h-170



h-170
















E3-10



E4-10



C1-3



Service-Dienstverlening-Serwis-Servis-Сервисная служба-Assistenza-Szerviz

B1		E1		L1		
B2		E2		L2		
B3		E3		L3		
B4		E4		L4		
B5		C1		L5		
B6				L6		

