




The picture does not represent the actual product


User manual
Benutzerhandbuch
Notice d'emploi
Manual de usuario
Manual do usuário
Manuale d'uso
Gebruiksaanwijzing


9290033382 9290033526



















Warning: Risk of electric shock



Warning

In order to prevent fire and electric shock accidents, it is forbidden to install and use electrical accessories not equipped with this product!


Please cut off the power before installation, disassembly, maintenance, or cleaning to avoid personal injury!


If unusual oscillating movement is observed, immediately stop using the ceiling fan and contact the manufacturer, its service agent or suitably qualified persons.



Attention points:

- The product must be installed by the manufacturer or professionally qualified person. The user must not install it by him/herself for safety reason.
- 2 The fan ceiling shall not be installed on the junction box or light keel suspended ceiling, and the hanging area must be able to bear a weight of at least 60 kg.
- 3. To avoid personal injury, the blades should be installed at least 2.3m height above the ground, and the outermost edge of the fan blades should be at least 0.5m away from the wall (when stretched)
- 4 The product is dimmable with the supplied dimmer ONLY. Do not connect to an additional dimmer.
- 5. Replaceable (LED only) light source by a professional: The LED light source contained in this luminaire shall only be replaced by the manufacturer or its service agent or a similar qualified person.
- 6. The means for disconnection of electrical wiring for fan ceiling must be incorporated in the fixed wiring in accordance with the wiring rules
- 7. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- It is recommended to check the connecting parts at least once a year, such as cross pin, blade frame, connecting screw and fan blades, etc., to ensure that the connection is still safe and reliable.
- Regular cleaning can keep the surface clean and bright. Soft brush or cloth is suggested to remove dust to avoid damaging the surface. When removing oil or deposits, wipe with a slightly damp cloth, Do not use abrasives or solvents. Avoid liquids on all electrical parts.
- The bearing of the fan motor comes with grease. Please do not add lubricating oil additionally.
- 11 This product contains a light source of energy efficiency class E.





Instruction of remote control

- 1. Light on.
- 2. Light off.
- 3. Natural wind flow (dynamic cycle of speed 1 to 6).
- Fan off.
- 5. All-off delay: 1 hour delay by pressing once, 2 hours delay by pressing twice, 4 hours delay by pressing 3 times, press any other button to cancel.
- 6. Brightness increase.
- 7. Brightness decrease.
- 8. Cool white: long press to slowly change from warm white to cool white, and short press to increase the color temperature by one level.
- Warm white: long press to slowly change from cool white to warm white, and short press to lower the color temperature by one level.
- 10.Night light:
 11. Decrease the fan speed -, with 6 speeds from the highest to the lowest.
- 12. Increase the fan speed +, with 6 speeds from the lowest to the highest.
- 13. Change fan rotate direction.
- 14.CCT 3000k-4400K-6500K.
- 15. Short press, go to the saved personalized light setting.
 - The default setting is 3000K.
 - A long press for more than 3 seconds saves your personalized light setting.
- 16. Timer to turn off light after 60s.
- 17. Battary(Not included).

Note: Switch via the wall switch 3000–4000–6500–6500+fan, the remote control distance is within 5 meters.

No need paring with remote control provided by Signify.

