







Assemble instruction
27980192-01
COUCHTISCH













2 PERSONEN




50 min



A x 22	B x 22	C x 48	D x 8	E x 32	P x 1
 Ø6*40mm	 Ø15*12mm	 Ø8*30mm	 Ø5*35mm	 Ø4*30mm	
G x 4	H x 2	J x 26	K x 2	L x 12	M x 4
		 Ø3.5*14mm	 M6*12mm	 M6*25mm	 M6*50mm
N x 10	O x 1	V x 12	W x 8	I x 4	
 Ø7*38mm	 M4	 Ø12mm	 Ø21mm	 25*25*3mm	



2




C x 12



Ø8*30mm


3



G x 4




4



G1 x 2	J x 4
	
	Ø3.5*14mm


5



C x 8

Ø8*30mm


6



A x 4

V x 4

E x 4



Ø6*40mm




Ø12mm



Ø4*30mm

7




E x 6



Ø4*30mm

8




G1 x 2

J x 4




Ø3.5*14mm

9




A x 10




Ø6*40mm

10



E x 8	V x 8
	
Ø4*30mm	Ø12mm


11




E x 8


Ø4*30mm

12

H x 2	E x 6
	 Ø4*30mm
	J x 6
	 Ø3.5*14mm




13



B x 4
 Ø15*12mm

14




B x 8



Ø15*12mm

15





B x 2




Ø15*12mm


16




N x 10	O x 1
	
Ø7*38mm	M4

17





I x 4	
	
25*25*3mm	
O x 1	M x 4
	
M4	M6*50mm

18





P x 1


K x 2	L x 12
	
M6*12mm	M6*25mm


O x 1

M4

19




A x 8	H x 2
	
Ø6*40mm	

19



G2 x 4	J x 8
	
	Ø3.5*14mm


20




D x 8

Ø5*35mm

21



22



W x 4




Ø21mm

B x 4



Ø15*12mm

23



W x 4




Ø21mm

B x 4



Ø15*12mm

24



J x 4



Ø3.5*14mm

P

