

ASSEMBLY INSTRUCTION


DE - MONTAGEANWEISUNG
 FR - INSTRUCTIONS DE MONTAGE
 DK - MONTAGEVEJLEDNING
 CZ - NÁVOD K MONTÁŽI
 ES - INSTRUCCIONES DE MONTAJE
 FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU
 SE - MONTERINGSANVISNING
 SI - NAVODILA ZA MONTAŽO
 TR - MONTAJ TALIMATI
 NO - MONTASJEANVISNING
 IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
 NL - MONTAGE INSTRUCTIE
 PT - INSTRUÇÕES DE MONTAGEM
 PL - INSTRUKCJA MONTAŻU
 HU - SZERELÉSI UTASÍTÁS



40 min



0 1 2 3 4 5 6 7 8 9 10 11 12 13 14	① x 4 HW-ST-02-060 (8x65)	 A x 1 SU-TB-AS-0745	 B x 2 SU-TB-LF-1518	 C x 2 SU-SC-ST-0402	 D x 4 SU-SC-BF-0292	 E x 6 SU-SC-AS-0144	 F x 1 SU-SC-MA-0399
	② x 4 HW-ST-07-044 (8.5x18x1)	 G x 1	 H x 4	 I x 2			
③ x 40 HW-ST-02-031 (6 x 45)							
④ x 40 HW-ST-07-123 (6.5 x 18 x 1)							
⑤ x 20 HW-ST-04-285 (50 x 30 x (13.0))							
⑥ x 40 HW-ST-07-141 (6.5 x 10.5 x 1.5)							
⑦ x 4 HW-ST-18-001 (4x98)							

