







23440002-01








No.	Size	Qty
A1	560x180x23mm	1
A2	560x180x23mm	1
B	549x287x23mm	1
C	526x274.5x20mm	1
D	324x180x33mm	1
E	322x170x20mm	2
F	312x155x20mm	2






(1)



(2)






(3)












(4)







(5)




(6)




(7)



(8)




door assembly process





door dis-assembly process

WARNING

This step is just for taking door off !







door pillar exchange process

WARNING


This step is just to switch the left door to the right door!




STEP 1




STEP 2



STEP 3






STEP 4




STEP 5

(9)



spare parts of glass buckle



(10)

