

ASSEMBLY INSTRUCTION

DE - MONTAGEANWEISUNG

FR - INSTRUCTIONS DE MONTAGE

DK - MONTAGEVEJLEDNING

CZ - NÁVOD K MONTÁŽI

ES - INSTRUCCIONES DE MONTAJE

FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU

SE - MONTERINGSANVISNING

SI - NAVODILA ZA MONTAŽO

TR - MONTAJ TALIMATI

NO - MONTASJEANVISNING

IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ

NL - MONTAGE INSTRUCTIE


PT - INSTRUÇÕES DE MONTAGEM

PL - INSTRUKCJA MONTAŻU

HU - SZERELÉSI UTASÍTÁS



15 min



0
1
2
3
4
5
6
7
8
9
10
11
12
13
14

① x 20




HW-ST-02-021
(6 x 20)

② x 8



HW-ST-02-069
(6 x 15)


③ x 1



HW-ST-18-001
(4x98)


Ⓐ x 4

VSU-SC-LF-0047




Ⓑ x 2

VSU-SC-LF-0048



Ⓒ x 1

VSU-SC-AS-0024



Ⓓ x 2

VSU-SC-BF-0031

