


CHESS


PB5579854-B180 – grey

PB5569854-B180 - black




THE ASSEMBLY REQUIRES TWO PEOPLE


COMPONENTS:



A X1
HEADBOARD X1




B - SIDERAILS X2
C - FOOTBOARD X1



D X4
METALIC
CORNER FRAME



E X4
PLASTIC LEG
H10cm



F X1
CENTRAL
WOOD FRAME




G X2
SIDE WOOD
FRAME




H X1
WOOD LEG
H27 CM



I X2
PLASTIC LEG
H3 CM



J X8
PLASTICS



K X1
LEG
ADJUSTER



L X4
SCREWS
3.5 x 16




M X2
SCREWS
4 x 50




N X32
M6x25




O X8
M6x60



P X1
M8x45




Q X4
M8x40



R X2


STEP 1:




I+M

I+M


A



STEP 2:



STEP 3:



STEP 4:

