






-DE- Montageanleitung
-IT- Istruzioni per il montaggio
-FR- Instructions de montage
-GB- Installation instructions
-ES- Instrucciones de montaje
-NL- Montagehandleiding
-PT- Instruções de montagem

-LT- Montavimo instrukcija
-LV- Montāžas instrukcija
-EE- Paigaldusjuhend
-PL- Instrukcja montażu
-CZ- Návod k montáži
-SK- Montážny návod
-BG- Инструкция за монтаж

Artikel/Serie Nr.: 846901xx0000

-HU- Szerelési útmutató
-RO- Instrucţiuni de montaj
-SI- Navodila za montažo
-HR- Upute za uporabu
-RS- Uputstva za upotrebu
-RU- Руководство по монтажу
-TR- Montaj Talimatı
-GR- Οδηγίες τοποθέτησης
-DK- Montagevejledning
-FI- Asennusopas
-SE- montageinstruktion
-NO- Monteringsanvisning
-IS- samsetningarlæðbeiningar



USB OUT
5V
DC IN
10V/1.2A



©WOFI LEUCHTEN
Wortmann & Filz GmbH, Im Langel 6, D-59872 Meschede
☒ kundendienst@wofi.de
+49/(0)2903-449 459
+49/(0)2903-449 449
www.wofi.de