












- (D) Montageanleitung
- (NL) Handleiding voor de montage
- (TR) Montaj talimatı
- (FR) Instructions de montage
- (CZ) Montážní návod
- (HU) Összeszerelési útmutató

- (GB) Assembly instructions
- (PL) Instrukcja montażu
- (RU) Инструкция по монтажу
- (IT) Istruzioni di montaggio
- (RO) Instrucțiuni de asamblare
- (SK) Montážny návod






PORTLAND POR17T10

2 / 6



1









2






3





4





5





1






2








3






ZUBEHÖR BELEUCHTUNG 006062ZB





Vitrinenschrank

Rückwand - innen



ZUBEHÖR 006090ZB Dimm & Touchschalter

