



Assembly Instruction


30166-100, 30166-165



AX16




B X56



CX56



DX8



E X16




Assembly Instruction

30166-100, 30166-165

1.

B X8


CX8



2.



DX8

E X16



Assembly Instruction

30166-100, 30166-165



Assembly Instruction




30166-100, 30166-165

5.

AX4


BX4

CX4



6.


CX12



Assembly Instruction

30166-100, 30166-165

7. CX32



Assembly Instruction

30166-100, 30166-165

