




Assembly instruction model "90xx-ER"

Leg DL05 with swivel

90xx-ER-DL05-WS



A x 1
03-001487



B x 8
NE M6x15
05-001036



C x 8
WKIZ M6x40
05-001888



D x 4
SSZ M6x20 C
05-001994



E x 4
M6
05-002042



F x 2
"10"
05-002043





G x 1
L4
05-001139



H x 1
L5
05-002050


1



A x 1
03-001487



B x 8
NE M6x15
05-001036





C x 8
WKIZ M6x40
05-001888




G x 1
L4
05-001139




H x 1
L5
05-002050



Regulation of leg
1. Untighten lower leg
2. Move down
Fix it



2



D x 4
SSZ M6x20 C
05-001994



E x 4
M6
05-002042



F x 2
"10"
05-002043

