













- (D) Montageanleitung
- (NL) Handleiding voor de montage
- (TR) Montaj talimatı
- (FR) Instructions de montage
- (CZ) Montážní návod
- (HU) Összeszerelési útmutató

- (GB) Assembly instructions
- (PL) Instrukcja montażu
- (RU) Инструкция по монтажу
- (IT) Istruzioni di montaggio
- (RO) Instrucțiuni de asamblare
- (SK) Montážny návod






CAMPINAS CAP17T20

2 / 6

1



2











3

W1  x12


W2  x4


C3  x20

4



G22  $\phi 18$ x1


T17  $\phi 8$ x1

J11  x1









5

P13  3,5x13 mm x2




L4  x2




L4




ZUBEHÖR BELEUCHTUNG 026030ZB




1




1




2




2




3



3





Vitrinenschrank

Rückwand - innen

ZUBEHÖR 006090ZB Dimm & Touchschalter

