


































Assembly Instruction


KLEIDERSCHRANK

Article number: 05540009/01




249 X 2 PCS 	359 X 6 PCS 	360 X 6 PCS 	150217 X 4 SET 	150218 X 4 SET 	315099 X 30 PCS 		
316947 X 2 PCS 	95200 X 2 PCS 	286 X 2 PCS 	565 X 2 PCS 	361 X 8 PCS 	102 X 8 PCS 	103 X 8 PCS 	157124 X 36 PCS 
100 X 44 PCS 	101 X 44 PCS 	172 X 36 PCS 	175 X 16 PCS 	4997 X 14 PCS 	147 X 72 PCS 	298176 X 24 PCS 	165593 X 20 PCS 
323257 X 1 SET 	7524 X 48 PCS 	285441 X 24 PCS 	285440 X 6 PCS 	291759 X 2 PCS 	298174 X 12 PCS 	298175 X 4 PCS 	145662 X 16 PCS 


1




2





3




4










7






8




9




10




11




12




13




14



15



16





19

9/11

x2

x2

407 mm





20

10/11

x2

x2


407 mm



21

11/11

x2



22

