

17130148/01



Wendy

BDSK Handels GmbH & Co. KG


Mergentheimer Straße 59

D-97084 Würzburg


E-Mail: Info@xxxlutz.at






2 PERS.





60 MIN






A x 17 	B x 17 	C x 8 	D x 4 	E x 6 	F x 3 	G x 8 
H x 4 	I x 16 	J x 2 	K x 2 	L x 5 	M x 24 	N x 4 
CL x 1 	CR x 1 	DL x 1 	DR x 1 			

0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18




1




3




4




5






6








7




8






9






10




11




12








13




14




15




16




To adjust the door vertically loosen the screw as shown and move up and down as needed.




To adjust the gap from the door to the main frame turn the screw clockwise or anti-clockwise as needed.




To adjust the door laterally adjust the screw as shown by turning clockwise or anti-clockwise.



Lock the final screws right in for product stability.



17



18

