

(D) Montageanleitung

(FR) Notice de montage

(NL) Handleiding voor de montage

(CZ) Montážní návod

(HU) Szerelési útmutató

(TR) Montaj talimati

(GB) Assembly instructions

(IT) Istruzioni di montaggio


(PL) Instrukcja montażu

(SK) Návod na montáž

(RO) Instrucțiuni de montaj

(RU) Инструкция по монтажу

5001.70 Timur 1






**Service • Assistenza • Dienstverlening • Serwis
Servis • Szerviz • Сервисная служба**

Name • Nom • Nome • Naam
Nazwa • Jméno • Názov • Név
Denumire • İsim • Название

Nr. • No. • N° • Номер • Č • Sz




Typ • Type • Tip • Típus • Tipo
Тип



Ax4 	Bx4 	Cx1 	Dx4 
--	--	--	--

① x1
② x4
③ x1




A




Ax4



B



C



D

