


# Paul Newhaus

## Removal instruction 834517

Instructions on how light sources and separate control gears can be removed without being permanently damaged for verification purposes by market surveillance authorities:

An Instruction on how to remove light source from a containing product is provided for reference:



The removal may only be carried out by a professional.


Step 1: Gently pry open the end cover in the notched position with a screw batch.



Step 2: Unscrew the light source plate using a screwdriver.



Step 3: Remove the light source.



Step 4: Use soldering iron to weld the lower lamp board



Step 5: An individual light source is removed out of the containing product.

