









Assemble instruction

27980181/02

BÜCHERREGAL








A	x36	B	x36	C	x60	D	x8	E	x24	F	x1	G	x4
													
6x35mm		Ø15x12mm		8x30mm		4x20mm		7x40mm		M4		Ø48x30mm	

H	x1	I	x1	J	x1	K	x1	L	x6
									
4x14mm		4x35mm				6x30mm		Ø20mm	


Assembly details




1



2




3




x3

B	x6	C	x12
			
Ø15x12mm		8x30mm	


4



x2


A	x24	C	x18
			
6x35mm		8x30mm	

5




B	x8	C	x6
			
Ø15x12mm		8x30mm	

6




E	x8	F	x1
			
7x40mm		M4	

7




B	x8	C	x6
Ø15x12mm		8x30mm	

8




E	x8	F	x1
7x40mm		M4	

9




B	x8	C	x6
			
Ø15x12mm		8x30mm	


10




E	x8	F	x1
			
7x40mm		M4	



D	x8	G	x4	L	x6
					
4x20mm		Ø48x30mm		Ø20mm	



H	x1	I	x1
			
4x14mm		4x35mm	
J	x1	K	x1
			
		6x30mm	