


ASSEMBLY INSTRUCTION

AUFBAUANLEITUNG / Návod / Instruktioner


GERHARD DESK













A 44X 15 x 12 mm	B 44X 7.5 x 35 mm	C 23X White	D 53X 8 x 32 mm	E 28X 6 x 13 mm
F 1SET 350 mm	G 8X 7 x 16.5 mm	H 13X 10 x 33.5 mm	I 20X 	J 20X 4 x 19 mm
K 4X 4 x 12 mm	L 22X Sanremo	M 2X 	N 16X 6 x 25 mm	O 1X
P 4X 6 x 40 mm	Q 4X 	R 2X 	S 1X 	




60
mn







9




10




11




12




13




14




15




16




17




18




19




20




21




22




23




24




25




26




27




28




29




30




31



32



33



34

