





-DE-	Montageanleitung
-IT-	Istruzioni per il montaggio
-FR-	Instructions de montage
-GB-	Installation instructions
-ES-	Instrucciones de montaje
-NL-	Montagehandleiding
-PT-	Instruções de montagem

-LT-	Montavimo instrukcija
-LV-	Montāžas instrukcija
-EE-	Päigaldusjuhend
-PL-	Instrukcja montażu
-CZ-	Návod k montáži
-SK-	Montážny návod
-BG-	Инструкция за монтаж

Artikel/Serie Nr.: 846901xx0000

-HU-	Szerelési útmutató
-RO-	Instrucţiuni de montaj
-SI-	Navodila za montažo
-HR-	Upute za uporabu
-RS-	Uputstva za upotrebu
-RU-	Руководство по монтажу
-TR-	Montaj Talimatı
-GR-	Οδηγίες τοποθέτησης
-DK-	Montagevejledning
-FI-	Asennusopas
-SE-	montageinstruktion
-NO-	Monteringsanvisning
-IS-	samsetningarlæðbeiningar



USB OUT
5V
DC IN
10V/1,2A



©WOFI LEUCHTEN
Wortmann & Filz GmbH, Im Langel 6, D-59872 Meschede
☒ kundendienst@wofi.de
☎ +49(0)2903 - 449 459
☎ +49(0)2903-449 449