



BEATA OT+2,5+OT



(D) Montageanleitung

(NL) Handleiding voor de montage

(TR) Montaj talimati

(F) Notice de montage

(CZ) Montážní návod

(GB) Assembly instructions

(HU) Szerelési útmutató













(PL) Instrukcja montażu



(RU) Инструкция по монтажу

(IT) Istruzioni di montaggio


(SK) Návod na montáž

(RO) Instrucțiuni de montaj







II



III



IV



Service • Assistenza • Dienstverlening • Serwis • Servis • Szerviz • Сервисная служба






Name • Nom • Nome • Naam •
Nazwa • Jméno • Názov • Név •
Denumire • Isim • Название

BEATA

Nr • No. • N° • Номер • Č • Sz

Type • Tipo • Tipus • Тип •
Тип • Tip

OT+2,5+OT




F1




X...

K




X...

B




X...

L



X...

D



X...

E



X...