











91-71101



PL- Instalować wyłącznie poza zasięgiem rąk

CZ- Instalujte pouze mimo dosah rukou

BG- Инсталирайте само извън обсега на ръцете

LT- Įdiekite tik rankų nepasiekiamoje vietoje

SK- Inštalujte iba mimo dosahu rúk

RO- Instalați numai la îndemâna copiilor

EN - Install only out of reach of hands

RUS- Устанавливать только вне досягаемости рук

SLO- Namestite samo izven dosega rok

LV- Instalējiet tikai rokas nepieejamā vietā

EE- Paigaldage ainult käed kättesaamatus kohas

UA- Встановлюйте тільки поза досяжністю рук

EL- Εγκαταστήστε μόνο μακριά από τα χέρια

DE- Nur außerhalb der Reichweite von Händen installieren

HU- Kizárólag kézen kívül helyezkedjen el

FR- Installez uniquement hors de la portée des mains

IT- Installare solo al di fuori della portata delle mani

ES- Instalar solo fuera del alcance de las manos