







ø8 mm






- (D) Montageanleitung
- (NL) Handleiding voor de montage
- (TR) Montaj talimatı
- (FR) Instructions de montage
- (CZ) Montážní návod
- (HU) Összeszerelési útmutató

- (GB) Assembly instructions
- (PL) Instrukcja montażu
- (RU) Инструкция по монтажу
- (IT) Istruzioni di montaggio
- (RO) Instrucțiuni de asamblare
- (SK) Montážny návod

1




2



3

W1  x16


C3  x12








4

S4  3x16 mm x2






ZM1  x2





5





6





1




2




3




1




2





3






4




5



ZUBEHÖR BELEUCHTUNG 026036ZB





Vitrinenschrank

Rückwand - innen

ZUBEHÖR 006090ZB Dimm & Touchschalter

