



PF Flat Fold Pet Stroller



Safety & Instruction Manual

www.wonderfold.com

WONDERFOLD®



WARNING

Safety Instructions for Pet Stroller

Please Read Before Use

Safety precautions are provided to ensure the correct use of this product and to prevent harm or damage to you and others. Please read all safety instructions carefully.

Warnings

- Do not use this carrier for children.
- Always supervise your pet when using the stroller.
- Do not let your pet climb into the stroller unassisted.
- Always use the included Pet Harness Latch, ensuring it is correctly adjusted and fitted to your pet's size.
- Always set the rear brake while loading and unloading pet.
- Always set the rear brake when the stroller is stationary.
- Engage all clips and buckles. Set parking brakes on hills or inclines.
- Do not exceed the stroller weight limit: PFM: 66 lbs. (30 kg) | PFL: 99 lbs (45 kg)
- When using the stroller with multiple pets, ensure the combined weight limit of the pets does not exceed the stroller's weight limit.
- Avoid hanging items or pressing down on the handlebar.
- Lift the frame over bumps or curbs.
- Always use with caution when the stroller is on uneven terrain or slopes.
- Do not use the stroller while running, jogging, or skating.
- Exercise caution near traffic and in crowded spaces.
- Keep fingers and body parts away from hinged joints when folding/unfolding.
- Keep pet clear when unfolding and folding the stroller.
- Keep the stroller away from strong heat sources and do not store in damp conditions.
- Do not disassemble or modify the stroller.
- Do not use it for any other purpose than the stroller's intended use.
- Only manufacturer approved parts and accessories should be placed on the stroller.
- WonderFold is not liable for any damage caused by your pet.
- Regularly inspect all parts for proper function and damage. Contact hello@wonderfold.com for replacement parts.

Specifications

Dimensions

PFM Unfolded:

27.8 in (L) x 21.7 in (W) x 42 in (H)
70.6 cm (L) x 55 cm (W) x 106.7 cm (H)

PFM Folded:

21.7 in (L) x 7.4 in (W) x 27.8 in (H)
55 cm (L) x 18.8 cm (W) x 70.5 cm (H)

PFL Unfolded:

33.5 in (L) x 25.6 in (W) x 43.7 in (H)
85 cm (L) x 65 cm (W) x 111 cm (H)

PFL Folded:

25.6 in (L) x 7.5 in (W) x 33.5 in (H)
65 cm (L) x 19 cm (W) x 85 cm (H)

Material

Frame: Iron, Plastic (POM, PA, PP, PA+GF)
Handlebar: TPU+EVA
Tire: EVA

Weight Capacity

PFM: 66 lbs. (30 kg)
PFL: 99 lbs. (45 kg)

Weight

PFM: 22.5 lbs. (10.2 kg)
PFL: 27 lbs. (12.3 kg)

Contents

Features..... 4

How to...

Unfold the Stroller / Adjust the Handlebar Height5

Use the Parking Brake / Use the Wind/Privacy Shade / Store the Mesh Top Window6

Attach and Use the Rear Wall / Use the Wipe Slot / Fold the Stroller7

Storing, Cleaning & Warranty8

Features



- **Handy Back Pocket:** Perfect for storing pet essentials, treats, or your personal items on the go.
- **Flat Fold Design:** Fold your wagon in seconds and stands on its own for stress-free storage and transport.
- **Customizable Handlebar:** Adjustable faux leather handlebar for pet owners of varying heights.
- **All-Terrain Wheels:** 360° swivel front wheels and a rear braking system deliver smooth and secure rides, no matter the adventure.

- **Easy Entry:** Effortlessly load and unload your pet with the spacious rear opening.
- **Ventilation and Visibility:** Large front and top mesh windows provide a cool, breezy space while keeping your pet connected to the world around them.
- **Built-In Leash Secure:** Securely locks your pet's leash in place for safe and worry-free strolls.
- **Privacy Cover:** Unzip and unroll the hidden cover for quiet moments; tuck it away seamlessly when not needed.





How to...

Unfold the Stroller

1. Unlock the side latch.
2. Pull the handlebar up to start unfolding the stroller.
3. Keep pulling the handlebar until you hear a click and the stroller is fully extended. Press the handlebar forward to confirm that it is securely locked.



Adjust the Handlebar Height


1. Press the button in the middle of the handlebar.
2. While the button is pressed, position the handle up or down to desired height.



How to...

Use the Parking Brake

1. Step down gently on the parking brake pedal to lock. To test and ensure the brake is engaged, try to push the stroller forward.
2. Lift the parking brake pedal upwards with your foot to release it.



Use the Wind/Privacy Shade

1. Completely unzip the pocket at the top of the stroller and pull down the wind/privacy shade.
2. Secure it to the bottom of the stroller on both sides by using the elastic loop.
3. Use as shown in figure 3.



Store the Mesh Top Window

1. Completely unzip the mesh top window and roll it towards the top of the stroller.
2. Use the elastic loop at the top to secure it in place.





How to...

Attach and Use the Rear Wall

1. Completely unzip the rear wall.
2. Attach the hooks below the rear pocket to the handlebar.
3. Use as shown in figure 3.



Use the Wipe Slot

1. Store wipes or poop bags in the inner mesh pocket inside the rear pocket.
2. Easily access through the zipper on the side of the pocket.



Fold the Stroller

1. Adjust the handlebar to the downward position.
2. Push the stroller down until it is completely folded.
3. Lock the side latch.





Storing the Pet Stroller

- Do not store in places with high temperature or humidity.
- Store indoors out of direct sunlight.
- Store in a dry place with low humidity.
- Keep out of reach of children.
- Do not store this product with objects placed on top of it when it is folded. Doing so may cause damage or deformation.

Cleaning

- Spot clean fabric and air dry. Avoid direct sunlight; fabric may fade with sunlight.
- Clean with a damp cloth; avoid abrasives, bleach, and silicone lubricants.
- After rain, wipe and dry completely before storing.
- For deep cleaning, use diluted detergent, then wipe and air dry in a shaded area.
- Avoid thinner, benzene, or alcohol on metal or plastic.

Warranty

One Year Limited Warranty

WonderFold warrants this product to be free from defects in material or workmanship for a period of one year from the date of purchase when used by the original owner according to the manufacturer's instructions. The warranty does not apply to damage caused by product alteration, or customer/user misuse or abuse of the product. Your sales receipt is your only record of the date of purchase. Warranty is subject to change at any time at the manufacturer's sole discretion. Please refer to wonderfold.com/pages/warranty for the latest version of the manufacturer warranty. Please contact WonderFold if you have any warranty questions or if you need replacement parts.

WONDERFOLD® pet

5796 Martin Rd
Irwindale, CA 91706
hello@wonderfold.com
1 (888) 681-1526



www.wonderfold.com