










ASSEMBLY INSTRUCTION

16940037 / 01







A		1PC x 6
B		1PC x 6
C		1PC x 6
D		1PC x 6
E		1PC x 6
F		1PC x 6
G		1PC x 6

2	 M6x30	4PCS x 6
3	 M6x45	6PCS x 6
4	 Ø6x14x1	10PCS x 6
5	 Ø8x16x3	2PCS x 6
7		6PCS x 6
8	 Allen key 4x60	2PCS


1




X6




2




X6




3




X6










4






X6









M		1PC
N		1PC
O		2PCS
P		2PCS
Q		2PCS
R		1PC
S		3PCS

1	 M6x25	10PCS
2	 M6x30	12PCS
3	 M6x45	2PCS
4	 Ø6x14x1	24PCS
6		2PCS
7		2PCS
8	 Allen key 4x60	1PC



1





2





3





4








5



6







X		2PCS x 4
Y		2PCS x 4
Z		1PC x 4
U		1PC x 4



2	 M6x30	10PCS x 4
4	 Ø6x14x1	10PCS x 4
8	 Allen key 4x60	1PC

1





X4

2



X4

3



X4

