



ambiente

40220007/01

non dimmer function



spare parts		
code	part	item no
A	 x2	40220007/01
B	 x1	40220007/01
C	 x2	40220007/01
D	 x2	40220007/01
E	 x60	40220007/01
F	 x120+3	40220007/01
G	 x1	40220007/01

CZ „Bez stmívací funkce“ pokyny k výrobku: bez stmívací funkce.

DE „Ohne Dimmfunktion“ Artikelhinweis: ohne Dimmfunktion.

HR „Bez funkcije prigušivanja“ Napomena o artiklu: bez funkcije prigušivanja.

SE "Utan dimmerfunktion" Artikelförklaring: utan dimmerfunktion.

SI „Brez funkcije zatemnitve“ Navodila za artikel: brez funkcije zatemnitve.