




Schreibtische der H-Serie / Q-Serie

Assembly instruction : desk range H.. / Q..



HS08, HS12, HS16 4x 4x	QS08, QS12, QS16 4x 4x
HS18 4x 4x	QS18 4x 4x
HS21 4x 4x 10x (4.5 x 25)	QS21 4x 4x 10x (4.5 x 25)
HS82 5x 5x 6x (4.5 x 25)	QS82 5x 5x 6x (4.5 x 25)



Schreibtische der H-Serie / Q-Serie

