

**WARNINGS!**

Please be aware of following!

To avoid scratching this furniture, it should be assembled on a soft layer – e.g. a rug.

Do not allow glasses to stand on the non-wood surface for a long time after use to avoid damage caused by high temperatures.

Do not place very hot or cold objects on the non-wood surface unless you are using sufficiently thick table mats.

Do not stand on the non-wood surface.

Do not use hard, pointed or sharp objects on the non-wood surface.

**IMPORTANT!**

It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months – This is in order to assure stability throughout the lifespan of the product.


**MAINTENANCE & CARE!**

Care and maintain the appearance of your unit.

Regular dusting with soft cloth will be adequate. For grime stains wipe unit with a damp cloth. Do not use washing powder or other products that contain a scouring agent, as this will scratch the surface.


If the product contains cushions, it is always recommended to keep them in a cushion box if they are not being used.

Generally, if you also use a cover to protect outdoor furniture, they will stay neat for a long time. Store out of season in a dry, frost-free and well-ventilated place, e.g. garage, carport or basement.




**ASSEMBLY INSTRUCTION**  
**23280046-01**

XXXLutz KG Roemerstrasse 39 AT-4600 Wels




A		1	E		8
B		1	F		9
C		1	G		1
D		1	H		9


# 1




# 2




# 3



4



5



# 6

