























Assembly Instruction

	1 x 1PC		2 x 1PC		3 x 1PC		4 x 2PCS								
															
	5 x 1PC		6 x 2PCS		7 x 1PC		8 x 1PC		9 x 1PC						
															
A x 12PCS		B x 1PC		C x 4PCS		D x 8PCS		E x 1PC		F x 2PCS		G x 2PCS		H x 2PCS	
															
I x 1PC		J x 1PC		K x 1PC		L x 1PC		M x 2PCS		O x 2PCS		N x 2PCS			
															


STEP 1





STEP 2



STEP 3



STEP 4



STEP 5

