





01

ASSEMBLY INSTRUCTION


27290014/01

XXXLutz KG
Roemerstrasse 39
AT-4600 Wels
Austria







 Ax36 Φ15*12	 Bx36 M6*32	 Cx16 Φ8*30	 Dx12 Φ12*10	 Ex12 Φ6*25	 Fx8 M8*10
 Gx8 M6*55	 Hx6 M6*Ø16*2	 Ix5 L80*40*10	 Jx4 Φ40*9	 Kx8 Ø8*15*M6	 Lx36 Φ20
 Mx6 10*12*5	 Nx1 #4	 Ox1 #5	 Px52 M3.5*14	 Qx18 M3.5*12	 Sx12 M3.5*25
 Tx3 L250mm	 Xx4 Ø8*35	 Yx10 M3*16	 Zx2 L=350		




03




04




05




06




07




08




09




10




11




12




13




14




15




16






17




18




19



20



21



22

