








HU 60 Blocktype Varianto

Montageanleitung / Notice de montage / Assembly instruction

Flex-Well Vertriebs
GmbH & Co.KG
Industriestr. 80
32120 Hiddenhausen
info@flex-well.de







2x 2x 4x



Ø 5mm


8x 8x 12x





H 30 / H 40 / H 50 / H 60 / KH 60-32 / HG 50 / HGH 50
H 50-68 / H 60-68 / H 50-89 / H 60-89 -Varianto

Montageanleitung / Notice de montage / Assembly instruction


Flex-Well Vertriebs
 GmbH & Co.KG
 Industriestr. 80
 32120 Hiddenhausen
 info@flex-well.de



4x 12x 2x 1x 4x










8x 2x 2x



SPU 50 Varianto Blocktype

Montageanleitung / Notice de montage / Assembly instruction

Flex-Well Vertriebs
GmbH & Co. KG
Industriestr. 80
32120 Hiddenhausen
info@flex-well.de



US 40 B/ 50 B/ 60 B Varianto (Blocktype)

Montageanleitung / Notice de montage / Assembly instruction

Flex-Well Vertriebs
GmbH & Co. KG
Industriestr. 80
32120 Hiddenhausen
info@flex-well.de

