


Pflege- und Gebrauchsanleitung




Bitte beachten Sie, dass Ihr Getränkespender nicht für Heißgetränke geeignet ist. Der Einsatz von Heißgetränken im Behälter kann zu einer Fehlfunktion des Produkts und/oder schweren Verletzungen führen. Reinigen Sie das Produkt wie jedes neue Produkt vor dem ersten sowie später nach jedem Gebrauch. Verwenden Sie dazu kaltes Wasser und spülen Sie es per Hand. Spülen Sie den Hahn mit sauberem Wasser aus.




1) Getränkespender erst am Bestimmungsort befüllen und niemals im vollen Zustand bewegen. Vor dem Befüllen mit Flüssigkeit sicherstellen, dass der Getränkespender auf einem ebenen Untergrund steht. Das Gerät beim Anheben niemals am Deckel, Oberteil oder Griff festhalten. Nur zerstoßenes Eis (Crushed Ice) verwenden, da größere Eisstücke den Getränkespender beschädigen könnten.


2) Den Zapfhahn vorsichtig durch die Dichtung führen. Dabei äußerst vorsichtig vorgehen und den Hahn nicht mit Gewalt durchschieben. Es kann helfen, den Hahn dabei im Uhrzeigersinn zu drehen.




3) Kunststoffmutter per Hand aufschrauben. Unbedingt beachten, dass der Zapfhahn weder zu fest noch zu locker sitzt.



4) Sollte sich die Dichtung einmal lösen, die Dichtung zuerst auf einer Seite zusammendrücken, dann in die Öffnung im Spender einsetzen.



Care and Use




Please remember that your Drink Dispenser is not made for Hot beverages. Any use of Hot Beverages in this container may result in product malfunction, and/or serious bodily harm. As with any new product, wash before first, and after every use. Use cold water, and wash by hand. Run clean water through the spout to clean.




1) Your Drink Dispenser should be filled only in the place of its intended use; it should never be moved when full. Ensure the Dispenser is placed on a flat even surface before filling with liquid. Never attempt to lift the product by Lid, Top or Handle. Use only crushed ice, as whole ice may damage your Drink Dispenser.


2) Gently insert the spout through the gasket. Make sure special attention is paid not to force the spout. It may have to be rotated clockwise to get it in.



3) The plastic nut should be screwed on by hand. Pay special attention not to over or under tighten the spout.



4) If the gasket should come out for any reason; first squeeze one side of the gasket to a smaller size, and insert into the hole on the dispenser.



When properly fitted, the gasket should fit the glass as illustrated on the left.