









Assemble instruction

27980063/01


DANZIG






A	x24	B	x24	C	x12	D	x24	E	x4	F	x4	G	x10
													
6x35mm		Ø15x12mm		8x30mm		3.5x14mm		7x40mm		M6x12mm		M6x35mm	
H	x1	I	x4	J	x2	K	x2	L	x2	M	x4	N	x4
													
M4				340mm		340mm				4x35mm		Ø20mm	
O	x4	P	x2										
													
M6x25mm		40x30x5mm											


Assembly details





1





2




3




D	x4
	
3.5x14mm	
K	x2
	
340mm	

4




B	x4
	
Ø15x12mm	
C	x4
	
8x30mm	

5




B	x4
	
Ø15x12mm	


6




C	x6
	
8x30mm	

7




E	x4	H	x1
			
7x40mm		M4	

8




B	x2
	
Ø15x12mm	

9




B	x2
	
Ø15x12mm	

10






B	x8
	
Ø15x12mm	

11



D	x4	I	x4
			
3.5x14mm			



12





P	x2
	
40x30x5mm	


F	x4	H	x1
			
M6x12mm		M4	


13




G	x10	H	x1
			
M6x35mm		M4	


14




O	x4	H	x1
			
M6x25mm		M4	

15




M	x4
	
4x35mm	

16




B	x4	N	x4
			
Ø15x12mm		Ø20mm	


17



18





19



D	x4	L	x2
			
3.5x14mm			

20



D	x8
	
3.5x14mm	

