










ASSEMBLY INSTRUCTION

16940061-01





① x 2	② x 1	③ x 1	④ x 1	⑤ x 6	⑥ x 6	⑦ x 6	⑧ x 6
⑨ x 6	⑩ x 6	⑪ x 6					




A x 28  M6x20 mm	B x 12  M6x30 mm	C x 48  M6x40 mm	D x 8  M8x20 mm	E x 12  M8x30 mm
F x 12  M8x45 mm	G x 88  Ø14x1 mm	H x 56  Ø16x1 mm	J x 24  M8 mm	K x 1  90x25x2 mm
L x 3  4 mm				




1




2




3




4




5



6





x6






7

x6




8


x6




9





x6




10



x6





x2





11

x6




12

x6



13

x6



14

x6

