





ASSEMBLY INSTRUCTION

09080026/01

Ax1 	Fx5 
Bx1 	Gx2 
Cx1 	Hx12  M6*18mm
Dx1  	Ix4  M6*20mm
Ex1 	Jx1 

