


ASSEMBLY INSTRUCTIONS FOR OL5400

CE UK
CA

1.1

GENERATION LIGHTING

05/15



IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION.

Carefully unpack and identify all parts before assembly. Bulb is not included.

1. Disassemble the bottom cover by unscrew to install the bulb (not included). See relamping label at socket area for type and Maximum allowed wattage.
2. Install the bottom cover by screws.
3. Follow enclosed supplement installation instruction for electrical and fixture installation onto ceiling.