


# Assembly Instructions For **P1204**

**CE** 11/12



**IMPORTANT**  
TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT  
BREAKER BOX  
BEFORE STARTING INSTALLATION

Carefully unpack and identify all parts before assembly. Bulb not included.

1. Slip fixture loop through fixture wires and then secure by screwing onto top of fixture.
2. Follow enclosed supplement installation instructions for electrical and fixture installation onto house ceiling.
3. Install light bulb (not included). See relamping label at socket area for type and maximum allowed wattage.
4. A. Slide glass shade through fixture until it checks onto upper section of fixture. Then secure into position by fastening with a washer and a hex nut. **IMPORTANT: DO NOT OVER TIGHTEN.**  
B. Install font by fastening with finial.  
C. Install hanging drop by hooking onto finial.

**FEISS®**

EST. 1955

GENERATION  
BRANDS™ 